



[N2E][1.0][1.0.1] TouchNooter 1.6.24

This will officially not work for 1.1

- **What it does:**
 - Enables ADB via uRamdisk
 - Installs su and Superuser.apk
 - Installs Busybox
 - Installs Button Savior
 - Installs Go Launcher
 - Installs NookColor Tools (To Enable Non-Market Installs)
 - Installs Gapps (Gmail, Market, Youtube, Others)
- **System Files that get Modified:**
 - /system/build.prop - Enabling Google Check In
 - packages.xml - Allows Gapps to install properly.
 - framework.jar - Should allow a proper Android ID to generate.
- **Changes:**
 - June 24, 2011 -
 - Removed: Multitouch Permission
 - Added: Modified framework.jar
 - June 22, 2011 - Fixed: Script not running at boot.
 - June 20, 2011 - Initial Release
- **Before you begin:**
 1. You must already have a registered Nook Simple Touch
 2. You must have a Gmail/Youtube linked Account. **IF** you used a Gmail account for B&N Registration you **should use that one for this process.**
 3. You must either have dd (Linux) or WinImage (Windows) software.
 4. You must have an **external microSDCard reader** or this will not work. Do NOT use the Nook Simple Touch.
 5. **You must have enough intelligence to follow instructions.**
- **Let's get started:**
 1. Download TouchNooter from here: [touchnooter-1-6-24.zip](#)
 2. **Linux:** Unzip and use dd if=touchnooter-1-6-24.img of=/dev/sdcard
 3. **Windows:** Unzip and use WinImage to "Restore Virtual Hard Disk Image" to your SDcard.
 4. **Windows Alternative:** <https://launchpad.net/win32-image-writer/+download>
 5. Power off your Nook Simple Touch.
 6. Insert TouchNooter SDcard into your Nook Simple Touch.
 7. Power on your Nook Simple Touch.
 8. You should see the screen "Rooted Forever".
 9. It will boot like normal and you should be asked to select a launcher now. (If not use Button Savior to go home. This will bring up the launcher chooser.)
 10. **That was the hard part, now to the simple stuff.**
 11. Upon boot unlock your screen.
 12. At the Android Welcome Screen skip Sign In.
 13. Enable Location Services when given the option.
 14. Connect to Wifi and launch Youtube from Go Launcher's App Drawer (Or the App Drawer of your Choice).
 15. Click the Menu button (The right one in the middle of the status bar).
 16. Select "My Channel" and Login using your Gmail Account.
 17. Exit Youtube and Launch Gmail from "Extras".
 18. Sync your Gmail Account and Exit. (If it fails to sync that is fine.)
 19. Open up Market and Accept Terms and Service.
 20. **If you made it this far your nook should be successfully Rooted. Go Download an App to make sure.**
 21. Enable Non-Market Installs by running the NookColor Tools App.
 22. If your Youtube fails to launch Uninstall and Reinstall Youtube from /data/app
 23. Go to Settings > Device Info > SdCard > UnMount > Format
- **Thanks To:**
 - **Arnold Snarb** - modified framework.jar
 - **nemith** - helping me figure out getting it to run at boot.
 - **JesusFreke** - For getting root.
 - **MrMuffin** - For the original Market Hack that we're using.
- **Currently Working On:** TouchNooter 1.11.x

ATTACHED THUMBNAILS



Motorola Atrix 4G

Alien ★ Build #4

NOOKcolor 1.3

ManualNooter 4.6.16 - Dev/Packager - Currently Stock

Nook 2nd Edition 1.1

TouchNooter 2.1.31 - Dev/Packager

Support my Gadget Fund - Donate with bitcoin: 1MyZxGhNaGsvrZWm43bH9uZ7n6r1wKaMF8

TV Shows anywhere with HuluPlus - [HuluPlus Referral](#)

File storage anywhere with Dropbox - [Dropbox Referral](#)